


Model: WBBC7623LC
Service code: WBBC7623LC2406
Engine part

WEIBANG[®]
GARDEN MACHINES


Weibang WB BC 7623 LC

r.v. 2024



1	Engine Spare parts price list	
No.	ID Zboží	Název
1	LC2P80F/L1256	Engine 23HP 2P80
2	5320115010	Bolt - 3/8-16*25.4 12.9
3	13910001	Belt AK32
4	13910014	Key 6,35+6,35+22
5	1391000202	Engine pulley
6	13910017	Clutch
7	13810010	Spring washer - 7/16
8	DL20204C2	Bolt - 7/16-20*2-1/2 10.9
9	1391000540	Left fixed plate
10	1391000740	Right fixed plate
11	1391000940	Engine protective net
12	0102006012	Bolt - M6*12
13	1391001040	Right support plate
14	1391001240	Left support plate
15	0102006016	Bolt - M6*16


Model: WBBC7623LC
Service code: WBBC7623LC2410
Blade system



2 Blade system Spare parts price list		
No.	ID Zboží	Název
1	50670001	Lock nut - M16*1.5
2	1392000202	Blade washer
3	1392000132	Blade
4	1392000322	Protective sleeve
5	1392000404	Blade shaft
6	6205-2ZS	Bearing 6205-2ZS
7	1392000502	Bearing washer
8	1392000602	Bearing spacer sleeve
9	1392000722	Bearing seat
10	1392000802	Blade pulley
11	50570002	Key 8*7*20
12	0301020000	Flat washer - ϕ 20
13	13920052	Nut - M20*1.5-L
14	13920053	Thin nut - M20*1.5-L
15	13920011	Belt
16	0102010020	Bolt - M10*20
17	0107012050	Bolt - M12*50
18	0206012000	Nut - M12
19	13920012	Bearing
20	1392001322	Bracket
21	0102010060	Bolt - M10*60
22	0901040000	Circlip - ϕ 40
23	6203-2RS	Bearing 6203-2RS
24	1392001802	Tensioner pulley
25	1392002102	Tensioner sleeve
26	1392002202	Tensioner arm
27	1392002502	Spacer sleeve
28	50680001	Nut - M10
29	0101010090	Bolt - M10*90
30	0302010000	Big flat washer - ϕ 10
31	4SC1908010	Cooper bush
32	13920026	Tensioning spring
33	2501006000A	Oil cup - M6
34	1392002704	Spacer sleeve for tensioning arm
35	1392002844	Blade cover
36	0302008000	Big flat washer
37	0102008020	Bolt - M8*20
38	0102010040	Bolt - M10*40
39	1392002922	Reinforcement plate
40	1392003344	Blade disc
41	1392003740	Height adjusting
42	0301008000	Flat washer - ϕ 8
43	0202008000	Nut - M8
44	1392004040	Left height adjusting rod
45	13920043	Rubber skin
46	1392004422	Pressure plate


No.	ID Zboží	Název
47	1392004540	Bumper
48	0102008040	Bolt - M8*40
49	13920046	Plug - Φ 20
50	1392004722	Support bracket
51	0301006000	Flat washer - ϕ 6
52	0202006000	Nut - M6
53	1392004822	Shaft for front baffle
54	1392004922	Front baffle
55	13920054	Blade Kit
56	13920056	Dust cover for bearing seat

Model: WBBC7623LC
Service code: WBBC7623LC2410
Main base plate




3	Main base plate Spare parts price list	
No.	ID Zboží	Název
1	0102008030	Bolt - M8*30
2	0302008000	Big washer - $\varnothing 8$
3	16620-Z120210-H7A0	Tank 15L
4	0102008020	Bolt - M8*20
5	1393000222	Tank bracket
6	0202006000	Lock nut - M6
7	0301006000	Flat washer - \varnothing
8	WB9670004	Relay
9	0102006016	Bolt - M6*16
10	1393000622	Rear deflector
11	0102010020	Bolt - M10*20
12	1393000701	Left support plate
13	4820113010	Bolt - 5/16-18x16
14	13930034	Rubber ring - $\Phi 25$
15	1393000801	Right support plate
16	1393003544	Main seat plate
17	13930018	Positioning sleeve
18	13930019	Pin - M8*60
19	1393002002	Lock sleeve
20	1393002102	Limited rod
21	1393002302	Belt limiter
22	0204010000	Metal lock nut - M10
23	0302010000	Big washer - $\varnothing 10$
24	0202010000	Lock nut - M10
25	0102010060	Bolt - M10*60
26	0901035000	Circlip - 35
27	1393003602	Drive tensioner
28	6202-2RS	Bearing 6202-2RS
29	1393002702	Tensioning cushion sleeve
30	1393003702	Tensioning arm
31	1392002502	Spacer sleeve
32	13930032	Tensioning spring
33	GM56A060000080	Solid bearing
34	0303008000	Big washer - $\varnothing 8$
35	0401008000	Spring washer - $\varnothing 8$
36	0101008020	Bolt - M8*20
37	1393003302	Spacer
38	Z122420014	Relay

Model: WBBC7623LC
Service code: WBBC7623LC2410
Rear axle



4 Rear axle Spare parts price list		
No.	ID Zboží	Název
1	13940025	Wheel nut - M12*1.25
2	13940026	Wheel 18*6,5-8
4	1001038000	Circlip - Φ 38
5	50510001	Pin - Φ 8*35 65mm
6	0111012040B	Wheel bolt - M12*1.25*40
7	1394000302	Brake hub flange
8	13940004	Brake hub assembly 160
8,1	13940030	Brake block
9	6007-2RS	Bearing 6007
10	1394000502	Left connecting plate
11	0301008000	Flat washer - Φ 8
12	0401008000	Circlip - Φ 8
13	0103008016	Screw - M8*16
14	0202008000	Nut - M8
15	13940009	Transmission
16	1394001002	Right connecting plate
17	4510117010	Nylon spacer
18	0801008020	Pin - 8*20
19	05012P5022	Split pin - 2.5*22
20	1394001402	Speed regulating plate
21	4SC3609020	Big washer
22	0401006000	Spring washer - ϕ 6
23	CM030000190	Fixing bolt
24	0102010020	Bolt - M10*20
25	1394002701	Left support seat
26	1394001602	Spacer sleeve
27	50020002	Bolt - M8*65
28	1394001702	Transmission pulley
29	1001016000	Circlip - Φ 16
30	1394002022	Left grass guard
31	0102008020	Bolt - M8*20
32	1394002322	Right grass guard
33	1394002801	Right support seat
34	1394002902	Spacer, Speed adjusting board


Model: WBBC7623LC
Service code: WBBC7623LC2410
Handle and controls



5 Handle and controls Spare parts price list		
No.	ID Zboží	Název
1	0202008000	Nut - M8
2	0301008000	Flat washer - φ8
3	1395000144	Left handle
4	1395000644	Right handle
5	1395001144	Left reinforcement rod
6	1395001244	Right reinforcement rod
7	0102008040	Bolt - M8*40
8	0102008045	Bolt - M8*45
9	0202006000	Lock nut - M6
10	1395001344	Battery bracket
11	13950057	Battery pad 2
12	DC12036	Battery
13	13950058	Battery pad 1
14	0128008020	Bolt - M8*20
15	1395001622	Battery pressure plate
16	13950059	Handle sheath 10*2*20
17	1395001702	Left parking lock hook
18	13950020	Left parking spring
19	1395002122	Brake steering handle
20	0801008024	Pin - 8*24
21	05012P5022	Splitpin - 2.5*22
22	0104006025	Screw - M6*25
23	0104006035	Screw - M6*35
24	0104006040	Screw - M6*40
25	1395002240	Hand guard
26	0103006020	Screw - M6*20
27	0302006000	Big washer - φ6
28	45A0323010	Big handle sheath
29	1395002349	Blade disc handle
30	13950025	Blade disc cable
31	0301006000	Flat washer - φ6
32	1301005000	Circlip - φ5
33	1395002640	Clutch handle
34	0104005025	Screw - M5*25
35	0302005000	Big washer - φ5
36	0104004012	Bolt - M4*12
37	1395002702	Binding post
38	1395002802	pressing plate
39	1395002902	Start switch pad
40	Z61C0300	Control switch
41	1395003002	Support sleeve
42	1395003101	Support plate
43	0102008020	Bolt - M8*20
44	0202005000	Lock nut - M5
45	0202003000	Lock nut - M3
46	Z42ED14000/22	Pressure plate for switch
47	13950032	Micro switch

No.	ID Zboží	Název
48	0104003025	Screw - M3*25
49	1395003301	Speed adjusting handle
50	0301005000	Flat washer - φ5
51	13950036	Limit plate
52	1395003701	Cover limit plate
53	0104005020	Screw - M5*20
54	2101008020	Handle ball BM8*20
55	0202010000	Nylon lock nut - M10
56	0302010000	Big washer - φ10
57	GT68WA08000/02	Spring
58	1395003801	Speed adjusting turntable
59	0501002016	Splitpin - 2*16
60	1395004001	Support plate
61	Z122241001	Throttle assembly
62	Z122241001	Throttle assembly
63	Z122245011A1	Rubber pad
64	13950042	Emergency stop
65	Z61E0300	Start switch
66	1395004344	Control panel
67	13950046	Brake cable
68	13950047	Clutch cable
69	13950048	Speed regulating cable
70	13950049	Throttle cable
71	4SC1307010C	Spring 1
72	13950050	Right parking torsion spring
73	1395005102	Right parking lock hook
74	0104006050	Screw - M6*50
75	13950054	OPC start spring
76	1395005549	OPC limit plate
77	Z61C0100	Key

Model: WBBC7623LC
Service code: WBBC7623LC2410
Wiring loom



6	Wiring loom Spare parts price list	
No.	ID Zboží	Název
1	BXS020A	Fuse 20A
2	13960002	Main wire
3	Z61E0300	Ignition switch
4	Z61C0100	Key
5	13950042	Emergency stop button
6	13950032	Neutral safety switch
7	Z61C0300	Blade hold-to-run switch
8	13960009	Battery black sheath
9	13960010	Battery red sheath
10	DC12036	Battery
11	WB9650008	Protective sheath 12*22
12	13960006	Electric clutch wire
13	Z122420014	Clutch relay
14	13960004	Electric clutch wire
15	13960005	Start motor wire
16	WB9650012	Black protective sheath - 14*8
17	WB9670004	Start relay
18	WB9650011	Red protective sheath - 14*8
19	13960003	Positive wire

Electrical schematic diagram

